




if you use the original KENWOOD IF-232C interface unit




use the following connections, then the IF-232C interface is not required



for self made IF-232C interface



Some Kennwoods works without resistor and transistor -- like TS-690.....

 CABLE- AND JUNCTIONS Service WORKFILE: CABNA09		
Switchmodul: NautiCom	receiver type: for IF-10D interface KENWOOD TS50, etc...	date: 01.09.98
Intern Info: for BoardTerminal receiver control		