

1


2

3

4


RC-SWL Switchbox

switched TX from computer



RC-SWL Plug

for 25-pin RS-232C socket




SUB-D Socket

Pin 3 TX

Pin 5 GND

Pin 2 DRX (data in)

Pin 7 GND




SUB-D Plug

to R8500 25-Pin RS-232C socket


you can choose between 2 sockets, but only one to the time

or for CI-V CT17 remote jack

ICOM-CT-17 control port



RC-SWL Plug



SUB-D Socket

Pin 6

Pin 5

Plug head

Plug shank (GND)

to R8500 remote jack

**CABLE- AND JUNCTIONS Service**

WORKFILE: CABRC10A

Switchmodul:

RC-SWL

receiver type:

ICOM IC-R8500

date:

01.09.98

Intern Info:

for RadioCom receiver control

1

2

3

4